



# Hardware Accessories and Gimbals

**NOTE:** This chair has been drilled and T-nutted to fit EEz-In® seat mounting hardware and accessories.

1. Read instructions completely before starting assembly.

NOTE: This product comes in two separate cartons. One contains the seat cushions; the seat base is in the other.

## MOUNTING INSTRUCTIONS

1. Position hardware on seat bottom and align it with the four T-nutted holes as illustrated in fig. 1. When mounting a slide or swivel casting, make certain that the locking rod is directed to the side of the seat.
2. Secure the seat mounting hardware to the seat with the four screws.
3. Periodically tighten the screws on seat bottom.

## GIMBAL ATTACHMENT\*

1. Position gimbal on seat bottom and align it with the two T-nutted holes as illustrated in fig. 2.
2. Secure gimbal to seat with the two provided 1/4-20 x 1" machine screws.

**\*NOTE:** Gimbal provided only with certain model EEz-In fishing chairs.

